

Installation Instruction for Pole Protection Sleeve

Instructions

- Use proper personal protective equipment (PPE)
- Ensure the work area is clean, dry, and well ventilated.
- When using a Propane (preferred)/ Butane gas torch or hot air gun, keep a safe distance from flammable materials.
- Do not touch the sleeve immediately after heating as the surface may be hot.
- Ensure the power supply is completely switched off and isolated before installation.

Installation Procedure

Step 1 – Surface Preparation

- Clean the substrate thoroughly using a lint-free cloth.
- Remove any oil, dust, grease, oxidation, or moisture.
- Ensure all sharp edges or burrs are removed to prevent sleeve damage.



Step 2 – Positioning the Sleeve

- Measure the installation area to ensure proper sleeve coverage.
- Wrap the sleeve around the substrate over the required section.
- Ensure correct overlap alignment if it is a wraparound sleeve.



Step 3 – Shrinking Process

- Start heating from the centre of the sleeve.
- Move the torch or heat gun in a circular motion to ensure uniform heating.
- Maintain a proper distance between flame and sleeve to avoid burning.
- Continue heating until the sleeve fully tightly grips the surface.



Step 4 – Final Inspection

- Check that the sleeve is evenly shrunk without wrinkles or air pockets.
- Ensure the sleeve has proper adhesion and full coverage.
- Allow the sleeve to cool naturally before applying mechanical pressure.



GALA SHRINK FIT