

INSTALLATION INSTRUCTIONS

SILICON OVERHEAD LINE COVER (GSOC)

Step by step installation procedure for insulating bare conductor using split type silicon rubber overhead line cover.

Unwind the split hose (silicon line cover) from its end and extend to the length of the insulation required. Due to property of the material the split hose will wind itself and protect the conductor.

The silicon line cover need to roll on the conductor throughout the length and it will automatically overlap around the circumference of the conductor.

Now, Installation of silicon overhead line cover is completed.

