

INSTALLATION INSTRUCTIONS.

HEAT SHRINK U-BOLT COATING

General Instructions :

Heat Shrink U-Bolt Coating supplied by us are in an expanded form. When heated above 125°C they attempt to shrink back to their original dimensions, conforming to the objects they cover.

Installation of Heat Shrink U-Bolt Coating.



Clean and de-grease the U-Bolt surface that will come into contact with U-Bolt H. S. Coating.



Place the Heat Shrink U-Bolt Coating over the U-Bolt.



Place the U-Bolt with Coating in place in a pre-warmed oven with temperature set point of 284-356°F (140-180°C). Shrinking time depends on oven temperature and cross section of U-Bolt.



After installation let the U-Bolt cool down to surrounding temperature and then can be used for its required application.

Installation complete.